

ABN 79 139 700 815

335 TOMAGO ROAD, TOMAGO NSW 2322

P: 02 49649660 E: sales@prolecaustralia.com.au

BOOTPRO OPERATING MANUAL

When used properly the Bootpro is designed to deliver effective cleaning to footwear. In order to do this, the motorized brushes must spin at a moderate rate of speed & care must be taken to use the machine correctly.

Please ensure you have read & understood the below operating procedure.

Please note the following

- -! Shoes must be tightly & securely laced & tied.
- -! No open footwear to be used on machine.
- -! If replacing any parts unplug & isolate the unit before you proceed.
- **Step 1.** Connect BootPro to correct mains power supply depending on which model you have.
- Step 2. Stand as close to the machine as possible.
- Step 3. Hold handle, press green button.
- **Step 4.** Insert shoe onto rotating brushes, ensure your boot touches the backstop, move your foot from side to side & back & forth.
- **Step 5.** Once clean press red button.
- **Step 5.** Repeat step 3,4 & 5 on 2nd shoe.